

ランパーツ

Item No.			Item No.			Item No.			Item No.										
(フラッシュ)			(オパック)			(フィッシャーストリーキー)			(ダブル グラス)										
AL	U	1001LT	E	×	AL	U	2375	E	廃	AL	SJ	4	F	×	AL	DP	21	J	×
	U	1001MD	E	×		U	2379	E	廃		SJ	6	F	×		DP	32	F	廃
	U	1001DK	E	×		U	3464	E	×		SJ	12	F	×		DP	33	F	×
	U	1002	F	廃		U	3476	E	廃		SJ	13	F	×		DP	34	J	△
	U	1003	F	×		U	3479	E	×		SJ	17	F	△		DP	35	J	×
	U	1004	F	廃		U	3515	E	×		SJ	18	F	廃		DP	43	J	×
	U	1006DK	E	△		U	3566	E	△		SJ	19	F	廃		DP	83	F	△
	U	1007	E	×		U	3581	H	△		SJ	20	F	廃		DP	109	F	廃
	U	1033	E	×		U	4219	H	廃		SJ	25	F	廃		DP	149	F	×
	U	1042LT	I	×		U	4243	E	廃		SJ	26	F	×		DP	192	J	×
	U	1042MD	I	×		U	4333	E	×		SJ	27	F	廃		DP	198	J	△
	U	1042DK	K	×		U	4345	H	廃		SJ	29	F	×		DP	202	H	廃
	U	1047	E	×		U	4352	F	×		SJ	31	J	△		DP	213	J	×
	U	1058	G	×		U	4459	J	廃		SJ	34	J	×		DP	214	J	×
	U	1064LT	D	×		U	4464	H	廃		SJ	36	F	廃		DP	224	F	×
	U	1064MD	D	×		U	4502	E	×		SJ	39	F	廃					
	U	1064DK	D	△		U	4522	E	×		SJ	41	F	廃					
	U	1066	G	×		U	4555	G	×		SJ	42	F	廃		(バリゲイト)			
	U	1067	I	△		U	4563	H	廃		SJ	44	F	×		VJ	64	F	×
	U	1076	E	廃		U	4631	E	○		SJ	45	F	廃		VJ	157	G	△
	U	1079	E	廃	UJ	72	H	×		SJ	46	F	×		VJ	158	G	△	
	U	2330	E	×	UJ	73	H	×		SJ	48	J	×		VJ	159	G	△	
	U	3406	E	廃	UJ	78	F	×		SJ	54	I	×		VJ	160	F	△	
	U	3410	H	廃	UJ	139	F	×		SJ	55	I	×		VJ	161	F	廃	
	U	3438	E	×	UJ	141	H	△		SJ	56	I	廃		VJ	166	G	△	
	U	3446	E	△	UJ	143	E	×		SJ	57	I	×		VJ	191	G	廃	
UB	U	3446	E	×	UJ	146	E	×		SJ	58	I	×						
U	U	3590	E	×	UJ	147	F	×		SJ	61	F	×						
					UJ	148	E	×		SJ	152	F	×		(グラデーション)				
					UJ	150	E	廃		SJ	198	F	△		GJ	64	F	×	
					UJ	153	E	×		SJ	242	F	廃		GJ	157	G	×	
					UJ	164	E	廃		SJ	243	F	×		GJ	158	G	△	
					UJ	165	F	×		SJ	244	F	×		GJ	160	F	廃	
					UJ	166	F	×		SJ	245	G	△		GJ	161	F	×	
					UJ	168	F	△		SJ	247	G	△		GJ	191	G	廃	
					UJ	183	F	×		SJ	258	G	△						
					UJ	184	E	×		SJ	259	F	×						
					UJ	185	E	廃		SJ	269	G	△		(others)				
					UJ	186	F	△		SJ	277	F	廃		JU	1	N	×	
					UJ	187	E	×		SJ	282	F	△						
					UJ	191	E	×		SJ	300	J	廃		AB	8	K	×	
					UJ	194	E	×		SJ	324	G	×		AB	12	M	廃	
					UJ	195	F	△		SJ	383	J	廃		AB	13	M	廃	
					UJ	196	E	廃		SJ	419	I	△		AB	14	J	廃	
					UJ	231	F	×		SJ	622	J	×		AB	16	F	廃	
					UJ	233	F	廃		SJ	652	J	×		AB	27	J	廃	
					UJ	234	E	廃											
					UJ	236	E	廃							AC	1	I	△	
					UJ	238	K	廃							AC	6	F	×	
					UJ	266	E	×							AC	7	F	廃	
					UJ	315	L	△							AC	16	L	廃	
					UJ	329	E	×							AC	24	F	廃	
					UJ	330	F	×							AC	29	H	廃	
					UJ	332	F	×							AC	30	H	廃	
					UJ	339	E	×							AC	37	F	廃	
					UJ	349	F	×											
					UJ	351	F	×											
					UJ	374	H	△											
					UJ	382	L	×											
					UJ	386	E	×											