

ランパーツ

Item No.			Item No.			Item No.			Item No.						
(フラッシュ)			(オパック)			(フィッシャーストリーキー)			(ダブル グラス)						
AL	U	1001LT E	×	AL	U	2375 E	廃	AL	SJ	4 F	△	AL	DP	21 J	×
	U	1001MD E	×		U	2379 E	廃		SJ	6 F	×		DP	32 F	廃
	U	1001DK E	×		U	3464 E	△		SJ	12 F	×		DP	33 F	×
	U	1002 F	×		U	3476 E	廃		SJ	13 F	×		DP	34 J	△
	U	1003 F	×		U	3479 E	×		SJ	17 F	×		DP	35 J	×
	U	1004 F	×		U	3515 E	×		SJ	18 F	廃		DP	43 J	×
	U	1006DK E	×		U	3566 E	△		SJ	19 F	△		DP	83 F	△
	U	1007 E	×		U	3581 H	△		SJ	20 F	△		DP	109 F	廃
	U	1033 E	×		U	4219 H	廃		SJ	25 F	×		DP	149 F	×
	U	1042LT I	×		U	4243 E	廃		SJ	26 F	×		DP	192 J	×
	U	1042MD I	×		U	4333 E	×		SJ	27 F	廃		DP	198 J	△
	U	1042DK K	×		U	4345 H	廃		SJ	29 F	×		DP	202 H	×
	U	1047 E	×		U	4352 F	△		SJ	31 J	△		DP	213 J	△
	U	1058 G	×		U	4459 J	廃		SJ	34 J	×		DP	214 J	×
	U	1064LT D	×		U	4464 H	△		SJ	36 F	△		DP	224 F	×
	U	1064MD D	×		U	4502 E	×		SJ	39 F	廃				
	U	1064DK D	×		U	4522 E	×		SJ	41 F	廃				
	U	1066 G	×		U	4555 G	△		SJ	42 F	廃	(バリゲイト)			
	U	1067 I	×		U	4563 H	廃		SJ	44 F	×	VJ	64 F	×	
	U	1076 E	廃		U	4631 E	△		SJ	45 F	△	VJ	157 G	○	
	U	1079 E	廃	UJ	72 H	△		SJ	46 F	×	VJ	158 G	△		
	U	2330 E	×	UJ	73 H	×		SJ	48 J	△	VJ	159 G	△		
	U	3406 E	廃	UJ	78 F	×		SJ	54 I	△	VJ	160 F	△		
	U	3410 H	廃	UJ	139 F	△		SJ	55 I	△	VJ	161 F	廃		
	U	3438 E	×	UJ	141 H	×		SJ	56 I	△	VJ	166 G	△		
	U	3446 E	×	UJ	143 E	×		SJ	57 I	×	VJ	191 G	△		
UB	U	3446 E	×	UJ	146 E	△		SJ	58 I	×					
	U	3590 E	×	UJ	147 F	×		SJ	61 F	×					
				UJ	148 E	×		SJ	152 F	△	(グラデーション)				
				UJ	150 E	廃		SJ	198 F	×	GJ	64 F	×		
				UJ	153 E	△		SJ	242 F	△	GJ	157 G	×		
				UJ	164 E	廃		SJ	243 F	×	GJ	158 G	△		
				UJ	165 F	×		SJ	244 F	△	GJ	160 F	廃		
				UJ	166 F	△		SJ	245 G	△	GJ	161 F	×		
				UJ	168 F	△		SJ	247 G	△	GJ	191 G	△		
				UJ	183 F	△		SJ	258 G	×					
				UJ	184 E	△		SJ	259 F	×					
				UJ	185 E	廃		SJ	269 G	△	(others)				
				UJ	186 F	×		SJ	277 F	廃	JU	1 N	×		
				UJ	187 E	△		SJ	282 F	△					
				UJ	191 E	×		SJ	300 J	△	AB	8 K	×		
				UJ	194 E	△		SJ	324 G	△	AB	12 M	廃		
				UJ	195 F	×		SJ	383 J	廃	AB	13 M	廃		
				UJ	196 E	廃		SJ	419 I	△	AB	14 J	廃		
				UJ	231 F	△		SJ	622 J	×	AB	16 F	×		
				UJ	233 F	廃		SJ	652 J	×	AB	27 J	廃		
				UJ	234 E	△									
				UJ	236 E	廃					AC	1 F	△		
				UJ	238 K	△					AC	6 F	×		
				UJ	266 E	×					AC	7 F	×		
				UJ	315 L	×					AC	16 L	廃		
				UJ	329 E	×					AC	24 F	廃		
				UJ	330 F	×					AC	29 H	廃		
				UJ	332 F	×					AC	30 H	廃		
				UJ	339 E	×					AC	37 F	△		
				UJ	349 F	×									
				UJ	351 F	×									
				UJ	374 H	×									
				UJ	382 L	×									
				UJ	386 E	×									