

サンゴーバン

| Item No. | | Item No. | | Item No. | | Item No. | | Item No. | | Item No. | | Item No. | |
|----------|---|------------|---|----------|---|-----------|---|-------------|---|-----------------|---|----------|---|
| (アンティック) | | S 114 C | × | (ストリーキー) | | (フラッシュ) | | (オパール) | | | | TC 182 F | ○ |
| M 1 A | × | S 115 C | △ | SY 1 G | △ | S 200LT D | × | OP 02 EE | 廃 | TY 182 H | ○ | TC 187 C | ○ |
| M 2 A | × | S 116 C | △ | SY 2 L | × | S 200MD D | × | OP 04 EE | 廃 | TC 264 C | ○ | TC 264 C | ○ |
| M 4 A | × | S 117 A | × | SY 4 G | ○ | S 200DK D | × | OP 05 EE | 廃 | | | | ○ |
| M 6 A | × | S 120 C | × | SY 5 H | × | S 201 E | × | OP 08 EE | 廃 | | | | ○ |
| M 9 A | × | S 124 C | × | SY 8 I | × | S 202 E | × | OP 09 EE | 廃 | NEW | | | |
| M 10 A | × | S 125 C | × | SY 9 H | × | S 203 E | △ | OP 10 EE | 廃 | TC 164 EE | △ | | |
| M 13 A | × | S 126 B | × | SY 10 H | × | S 204 E | △ | OP 11 EE | 廃 | | | | |
| M 14 A | × | S 127 A | × | SY 11 L | × | S 205 E | × | OP 12 EE | 廃 | | | | |
| M 16 A | × | S 129 C | × | SY 12 L | × | S 206 E | ○ | OP 13 EE | 廃 | | | | |
| M 17 A | × | S 132 C | × | SY 13 I | × | S 207LT D | × | OP 14 EE | 廃 | (FLKパターン) | | | |
| M 18 A | × | S 133 C | × | SY 14 I | × | S 207MD D | × | OP 16 EE | 廃 | FLK 01 A | ○ | | |
| M 21 A | × | S 135 C | × | SY 15 H | × | S 207DK D | × | OP 17 EE | 廃 | FLK 02 D | ○ | | |
| S 3 E | × | S 143 A | × | SY 16 H | × | S 208 E | × | OP 19 EE | 廃 | FLK 03 D | ○ | | |
| S 5 C | × | S 144 C | × | SY 17 I | × | S 209 E | △ | OP 21 EE | 廃 | FLK (3mm) 04 AA | × | | |
| S 8 C | × | S 150 C | △ | SY 18 I | × | S 210 E | × | OP 181 EE | 廃 | FLP (4mm) 04 B | △ | | |
| S 11 C | × | S 151 B | △ | SY 20 I | × | S 211 E | × | | | | | | |
| S 14 A | × | S 152 A | × | SY 21 I | △ | S 212LT E | × | | | (FWパターン) | | | |
| S 18 A | × | S 155 C | × | SY 22 I | × | S 212DK E | × | | | FW 01 C | ○ | | |
| S 25 A | × | S 156 B | × | SY 23 I | × | S 213 E | × | (ニューアンティック) | | FH 01 D | ○ | | |
| S 30 A | × | S 165 B | × | SY 24 I | × | S 214 D | × | | | FK 01 D | ○ | | |
| S 31 A | × | S 166 A | △ | SY 25 I | △ | S 215 D | × | N 001 A | 廃 | | | | |
| S 34 C | △ | S 180 E | × | SY 26 G | × | S 216 D | × | N 009 C | 廃 | | | | |
| S 39 C | × | S 181 E | × | SY 27 L | × | S 217 D | × | N 013 A | 廃 | (キャセドラル) | | | |
| S 44 A | × | S 182 E | × | SY 28 H | △ | S 218 D | × | N 042 A | 廃 | CX 00 A | ○ | | |
| S 48 A | × | S 183 E | × | SY 29 L | × | S 219 D | × | N 062 B | 廃 | CX 10 B | ○ | | |
| S 51 B | × | S 185 E | × | SY 34 L | × | S 220 D | △ | N 122 B | 廃 | CX 12 B | ○ | | |
| S 52 C | × | S 186 E | × | SY 35 H | × | S 221 D | × | N 224 A | 廃 | CX 14 C | ○ | | |
| S 53 C | × | S 261 A | × | SY 36 G | × | S 222 J | × | N 244 A | 廃 | CX 17 C | ○ | | |
| S 54 C | × | S 265 A | × | SY 39 G | × | S 223 J | × | N 300 B | △ | CX 23 C | ○ | | |
| S 56 C | × | S 267 B | × | SY 41 I | △ | S 224 K | × | N 1570 A | 廃 | CX 24 C | ○ | | |
| S 57 C | × | S 270 C | × | SY 42 I | × | S 226 D | × | N 2000 A | 廃 | CX 31 D | ○ | | |
| S 61 B | × | S 271 C | × | SY 44 G | × | S 227 D | × | N 3315 A | 廃 | CX 32 D | ○ | | |
| S 62 C | × | | | SY 45 H | × | S 1176 D | × | | | CX 34 D | ○ | | |
| S 65 C | × | | | SY 50 I | × | S 1186 D | × | | | CX 37 B | ○ | | |
| S 66 C | × | | | SY 51 L | × | S 1187 D | × | (パターンガラス) | | CX 44 B | ○ | | |
| S 68 B | × | | | SY 52 L | △ | S 1225 D | × | TC 042 A | ○ | CX 47 C | ○ | | |
| S 70 B | × | (クリアリーミー) | | SY 53 I | × | | | TC 043 C | ○ | CX 67 C | ○ | | |
| S 71 B | × | R 1 A | × | SY 55 I | × | | | TC 046 CC | ○ | CX 71 C | ○ | | |
| S 72 C | × | | | SY 56 I | × | | | TY 046 D | △ | | | | |
| S 77 A | × | | | S 230 F | △ | | | TC 060 A | ○ | | | | |
| S 82 A | × | | | S 231 F | × | | | TC 061 E | ○ | | | | |
| S 83 A | × | (クリアシーディー) | | S 232 F | △ | | | TC 062 E | △ | | | | |
| S 84 A | × | SB 01 A | × | S 233 F | × | | | TC 063 G | × | フローラガラス | | | |
| S 85 A | × | | | S 234 F | × | | | TC 064 D | ○ | F 00 A | × | | |
| S 87 A | × | | | S 235 F | × | | | TC 071 C | ○ | F 01 A | ○ | | |
| S 89 B | × | | | S 236 F | × | | | TY 071 D | △ | F 02 B | ○ | | |
| S 90 C | × | | | S 237 F | × | | | TC 072 C | △ | F 03 B | × | | |
| S 93 C | × | | | S 238 F | × | (クラックル) | | TC 076 G | △ | F 04 B | ○ | | |
| S 95 C | × | (オパック) | | S 239 F | △ | CR 1 A | × | TC 080 D | ○ | | | | |
| S 97 C | × | OPK 4 F | × | S 661 F | × | CR 3 A | × | TC 089 C | ○ | | | | |
| S 98 A | × | OPK 5 F | × | B 1182 F | × | CR 5 A | × | TC 097 D | × | | | | |
| S 100 A | × | OPK 8 F | × | S 4055 F | × | CR 7 A | × | TC 101 A | △ | ガラスファブリック | | | |
| S 103 C | × | OPK 9 F | × | BF 06 I | × | CR 8 A | × | TC 113 G | △ | ランパーツガラス | | | |
| S 104 C | × | OPK 14 F | × | BF 12 I | × | CR 9 A | △ | TC 115 G | × | | | | |
| S 105 C | × | OPK 21 F | × | BF 13 I | × | CR 10 A | × | TC 121 E | ○ | GAL 001 B | △ | | |
| S 106 A | × | OPK 339 F | × | BF 18 I | × | CR 11 A | × | TC 155 A | ○ | GAL 002 A | ○ | | |
| S 107 C | × | | | BF 20 I | × | CR 13 A | × | TC 157 C | ○ | GAL 003 C | △ | | |
| S 108 C | × | | | BF 152 L | × | CR 14 A | × | TC 159 A | ○ | GAL 004 E | ○ | | |
| S 109 C | × | | | | | CR 21 A | × | TB 178 D | △ | GAL 005 D | ○ | | |
| S 110 C | × | | | | | CR 22 A | × | TC 178 C | ○ | GAL 006 D | △ | | |
| S 111 C | × | | | | | CR 180 G | △ | TA 182 H | ○ | | | | |