

サンゴーバン

Item No.		Item No.		Item No.		Item No.		Item No.		Item No.		Item No.	
(アンティック)		S 114 C	×	(ストリーキー)		(フラッシュ)		(オパール)		NEW			
M 1 A	×	S 115 C	×	SY 1 G	○	S 200LT D	×	OP 02 EE	廃	TC 046 C	×		
M 2 A	×	S 116 C	×	SY 2 L	×	S 200MD D	×	OP 04 EE	廃	TY 046 D	△		
M 4 A	×	S 117 A	△	SY 4 G	○	S 200DK D	×	OP 05 EE	廃	TC 063 G	×		
M 6 A	×	S 120 C	×	SY 5 H	△	S 201 E	×	OP 08 EE	廃	TC 076 G	×		
M 9 A	×	S 124 C	×	SY 8 I	×	S 202 E	×	OP 09 EE	廃	TC 121 E	○		
M 10 A	×	S 125 C	×	SY 9 H	×	S 203 E	△	OP 10 EE	廃				
M 13 A	×	S 126 B	×	SY 10 H	×	S 204 E	×	OP 11 EE	廃	FLK 01 A	○		
M 14 A	×	S 127 A	×	SY 11 L	×	S 205 E	×	OP 12 EE	廃	FLK 02 D	×		
M 16 A	×	S 129 C	×	SY 12 L	×	S 206 E	○	OP 13 EE	廃	FLK 03 D	○		
M 17 A	×	S 132 C	×	SY 13 I	×	S 207LT D	×	OP 14 EE	廃	FW 01 C	×		
M 18 A	×	S 133 C	×	SY 14 I	×	S 207MD D	×	OP 16 EE	廃				
M 21 A	×	S 135 C	×	SY 15 H	×	S 207DK D	×	OP 17 EE	廃				
S 3 E	×	S 143 A	×	SY 16 H	×	S 208 E	×	OP 19 EE	廃				
S 5 C	×	S 144 C	×	SY 17 I	×	S 209 E	×	OP 21 EE	廃	(キャセドラル)			
S 8 C	×	S 150 C	×	SY 18 I	×	S 210 E	×	OP 181 EE	廃	CX 00 A	×		
S 11 C	×	S 151 B	×	SY 20 I	×	S 211 E	×			CX 10 B	廃		
S 14 A	×	S 152 A	×	SY 21 I	△	S 212LT E	×			CX 12 B	廃		
S 18 A	×	S 155 C	×	SY 22 I	△	S 212DK E	×			CX 14 C	廃		
S 25 A	×	S 156 B	×	SY 23 I	×	S 213 E	×	(ニューアンティック)		CX 17 C	廃		
S 30 A	×	S 165 B	×	SY 24 I	×	S 214 D	△			CX 23 C	廃		
S 31 A	×	S 166 A	×	SY 25 I	×	S 215 D	×	N 001 A	廃	CX 24 C	廃		
S 34 C	×	S 180 E	×	SY 26 G	×	S 216 D	×	N 009 C	廃	CX 31 D	廃		
S 39 C	×	S 181 E	×	SY 27 L	×	S 217 D	×	N 013 A	廃	CX 32 D	廃		
S 44 A	×	S 182 E	×	SY 28 H	×	S 218 D	×	N 042 A	廃	CX 34 D	廃		
S 48 A	×	S 183 E	×	SY 29 L	×	S 219 D	×	N 062 B	廃	CX 37 B	廃		
S 51 B	×	S 185 E	×	SY 34 L	×	S 220 D	△	N 122 B	廃	CX 44 B	廃		
S 52 C	×	S 186 E	×	SY 35 H	×	S 221 D	×	N 224 A	廃	CX 47 C	廃		
S 53 C	×	S 261 A	×	SY 36 G	×	S 222 J	×	N 244 A	廃	CX 67 C	廃		
S 54 C	×	S 265 A	×	SY 39 G	×	S 223 J	×	N 300 B	○	CX 71 C	廃		
S 56 C	×	S 267 B	×	SY 41 I	△	S 224 K	×	N 1570 A	廃				
S 57 C	×	S 270 C	×	SY 42 I	×	S 226 D	×	N 2000 A	廃				
S 61 B	×	S 271 C	×	SY 44 G	×	S 227 D	×	N 3315 A	廃				
S 62 C	×			SY 45 H	×	S 1176 D	×			フローラガラス			
S 65 C	×			SY 50 I	×	S 1186 D	×			F 00 A	×		
S 66 C	×			SY 51 L	×	S 1187 D	×	(パターンガラス)		F 01 A	○		
S 68 B	×			SY 52 L	△	S 1225 D	×			F 02 B	△		
S 70 B	×	(クリアリーミー)		SY 53 I	×					F 03 B	△		
S 71 B	×	R 1 A	×	SY 55 I	×					F 04 B	△		
S 72 C	×			SY 56 I	×								
S 77 A	×			S 230 F	△								
S 82 A	×			S 231 F	×								
S 83 A	×	(クリアシーディー)		S 232 F	△								
S 84 A	×	SB 01 A	×	S 233 F	×								
S 85 A	×			S 234 F	×								
S 87 A	×			S 235 F	×								
S 89 B	×			S 236 F	×								
S 90 C	×			S 237 F	×								
S 93 C	×			S 238 F	×	(クラックル)							
S 95 C	×	(オパック)		S 239 F	△	CR 1 A	×			TC 101 A	△	GAL 001 B	×
S 97 C	×	OPK 4 F	×	S 661 F	×	CR 3 A	×			TC 113 G	×	GAL 002 A	廃
S 98 A	×	OPK 5 F	×	B 1182 F	×	CR 5 A	×			TC 115 G	△	GAL 003 C	△
S 100 A	×	OPK 8 F	×	S 4055 F	×	CR 7 A	×			TC 155 A	○	GAL 004 E	○
S 103 C	×	OPK 9 F	×	BF 06 I	×	CR 8 A	×			TC 157 C	廃	GAL 005 D	廃
S 104 C	×	OPK 14 F	×	BF 12 I	×	CR 9 A	△			TC 159 A	△	GAL 006 D	△
S 105 C	×	OPK 21 F	×	BF 13 I	×	CR 10 A	×			TB 178 D	○		
S 106 A	×	OPK 339 F	×	BF 18 I	×	CR 11 A	×			TC 178 C	○		
S 107 C	×			BF 20 I	×	CR 13 A	×			TA 182 H	○		
S 108 C	×			BF 152 L	×	CR 14 A	×			TC 182 F	○		
S 109 C	×					CR 21 A	×			TY 182 H	×		
S 110 C	×					CR 22 A	×			TC 187 C	×		
S 111 C	×					CR 180 G	×			TC 264 C	廃		